

# MONTERINGSANVISNING

## ASSEMBLY INSTRUCTIONS

---

### VIGA HÄNGSTOL

Art. Nr 9549-409




# Assembly instructions | Monteringsanvisning



**IMPORTANT: READ CAREFULLY AND RETAIN FOR FUTURE REFERENCE**

## Assembly Instructions

|   |            |       |
|---|------------|-------|
| A |            | 1PC   |
| B |            | 1PC   |
| C |            | 1PC   |
| D |            | 1PCS  |
| E |            | 1PCS  |
| F |            | 1PCS  |
| G | <br>M10*60 | 2 PCS |
| H | <br>M10*55 | 2 PCS |
| I |            | 1 PC  |
| J |            | 1 PC  |
| K |            | 1 PC  |



### IMPORTANT & WARNINGS:

- . Remove all parts from packaging carefully.
- . This is a heavy unit!! When assembling and unassembling we recommend that 2 or more adults are involved.
- . Keep children & Pets away when assembling or unassembling.
- . Do not climb on the frame
- . This product is not a toy and should NOT be used as a swing under any circumstances as this could result in injury.
- . Max recommended weight is 120Kgs/ 250Lbs.
- . This product is only designed to seat 1 person at any given time. DO NOT exceed this as this could damage the product and cause injury; and void your warranty.
- . Keep all flame and heat sources well away from this product at all times.
- . Take care not to trap fingers whilst assembling and unassembling.
- . When not in use please store away in a cool and dry place away from any heat source.

# MONTERINGSANVISNING

## ASSEMBLY INSTRUCTIONS

---

### VIGA HÄNGSTOL

Art. Nr 9550-408



# Assembly instructions | Monteringsanvisning



| NO | Picture | Qty | NO | Picture | QTY           |
|----|---------|-----|----|---------|---------------|
| A  |         | 1PC | G  |         | 2PCS(M 10*60) |
| B  |         | 1PC | H  |         | 2PCS(M 10*55) |
| C  |         | 1PC | I  |         | 1PC           |
| D  |         | 1PC | J  |         | 1PC           |
| E  |         | 1PC | K  |         | 1PC           |
| F  |         | 1PC |    |         |               |

