

## Förenklat handhavande Simplified operation

KC 02/ -03/ -04

### Svenska

- Packa upp vågen och ta bort allt emballage, placera den på ett stabilt underlag som med god marginal klarar den aktuella belastningen (Vågens kapacitet + vågens egenvikt).
- Ta bort transportsäkringsfjäders som finns under belastningsplattan.
- Kontrollera att belastningsplattans fästskruvar är väl åtdragna.
- Tryck på belastningsplattan några gånger.
- Om viktvisaren inte visar "0", justera med den räfflade nollställningsanordningen (finns under belastningsplattan).

### **OBSERVERA!**

- Vagningsobjektet får inte vara så stort att det finns risk för att det faller av vågplattan och ger användaren skada.
- Vagningsobjektets tyngdpunkt skall alltid med god marginal vara innanför belastningsplattans mått.

# English

- Unpack the scale and remove packing material, place the scale on a strong and stable surface.
- Remove transport spring which is located under the top platform.
- Make sure all screws that are connected to the load support are tightened.
- Press on the load support a few times to remove any tensions.
- If the pointer does not indicate "0", adjust with the brass screw located under the load support.

## **OBSERVE!**

- If the weighing object is too big there is a risk that the object could fall off the load support and hurting the user.
- The objects weight center must always be as close to the center as possible.

[www.liden-weighing.se](http://www.liden-weighing.se)